

# **PWP-2W/2B Installation Instructions**

## **OPERATION:**

The PWP-2 transmitter is a portable pendant transmitter. There are 2 buttons allowing manual activation.

Pressing either of the buttons will activate the transmitter as long as the button is depressed.

## **TRANSMITTING KEY CODES:**

The output transmission from the PWP-2 is dependent on which button is activated and how long it is held activated. Each button causes a unique key code to be transmitted when initially activated. If the button is held activated for a period of 3 seconds the key code transmitted changes to yet a different code. This format allows 4 functions to be controlled by just two buttons.

## **SUMMARY:**

Code 1 -- Button #1 initial activation

Code 2 -- Button #2 initial activation

Code 3 -- Button #1 held on after 3 seconds

Code 4 -- Button #2 held on after 3 seconds

**BATTERY LIFE:** 50,000 operating seconds or 10 years.

**MAINTENANCE FREE:** Maintenance cannot be done on this transmitter.

The transmitter is sealed against moisture intrusion and the unit has no provision for changing batteries.